

PREPARING AN TEST PATCH USING NEW GENERATION 100®

NON-SKID AND GLAZE COAT IN ONE APPLICATION:

1. Prep demo area as per label directions.
2. When dry, measure off 50 square feet. Outline area with duct tape. Split area directly down the middle with one strip of duct tape. Prime area if required.
3. When Primer is dry, but before 24 hours, apply entire Intro Kit to entire 50 square feet. Spread out uniformly. (This gives 20 mils and is equivalent to 1 gallon/80 square feet).
4. Immediately broadcast alumina evenly into half of area (25 square feet). Use 1/2 lb. of #12-24 alumina. (This is equivalent to 2 lbs./100 square feet). (Broadcast by hand, with a spreader, sieve or small box with holes in the bottom.)
5. Backroll alumina until uniform. Do not porcupine.
6. Wearing gloves, remove tape before coating dries.

